

# Instructions

## ACTION-4 RAPID RETICLE



once you zero your scope use paint or marker to indicate your base zero.

If you zero the scope using the single dot, the scope will be zeroed using the single dot, the center dot on reticle #2, and the center dot of reticle #3. Then reticle #4 can be used to aim at the neck area using bean bags or impact rounds ; and the projectile will hit at the center of the box of reticle #4.

If the scope is zeroed at 15 yards using the top dot of reticle#2, then it will be zeroed at 25yards using the center dot and 45 yards using the bottom dot; exact impact and direct impact rounds.

If the top dot of reticle #2 is zeroed, then the top dot of reticle #4 can be used for direct fire.

It is recommended that you practice shooting with the desired reticle prior to deploying the system .

**NOTE:** Keep the dot you are shooting with in the center of scope when in use.




Target Turret Windage and elevation knobs



page -2

Installing 2032 3-volt battery

1. remove cap
2. battery + up



3. replace cap

This reticle is 18" wide at 25 yards. good for ranging individual at 25 yards on shoulders

Multi Reticle Switch  
Turn knob to desired reticle.

33mm tube constructed of durable high quality aluminum and glass.

